

Viewfinder System



Electronic Viewfinder EVF-1, K2.72008.0



Viewfinder Cable
35 cm, KC 150-S K2.72012.0
65 cm, KC 151-S K2.72013.0
200 cm, KC 152-S K2.72014.0



Viewfinder Mounting Bracket, VMB-1 K2.72009.0



Viewfinder Extension Bracket VEB-1 K2.72000.0

Cables



HDTV BNC Cable (HD-SDI)
0,25 m black K2.47840.0, blue K2.47841.0
2 m black K2.47842.0, blue K2.47843.0
10 m black K2.47844.0, blue K2.47845.0
20 m black K2.47838.0, blue K2.47839.0



UMC Connection Cable K-UMC3-ALEXA, K2.65239.0



ALEXA 12V Accessory Cable KC 154-SP-S, K2.72031.0 (coiled)



ALEXA Ethernet Cable 3m KC 153-S, K2.72021.0

Monitor



7" HD/SD Monitor HDM-7 incl. power cable, K2.66106.0
needed: Mounting Arm & BNC cable (RG59)



ALEXA 12V Accessory Cable KC 154-SP-S K2.72031.0 (coiled)



Univ. Mounting Arm, UMA-120 K2.65020.0



Monitor Arm MMA-65 K2.41101.0
recommended for HDM-7



Univ. Mounting Arm, UMA-240 K2.41100.0

Basic WRS Components



Controlled Lens Motor CLM-3 K0.60057.0



Controlled Lens Motor CLM-2 K2.52036.0



Console CLM-2 K2.52035.0



Wireless Control Unit WCU-3 K2.65155.0



Universal Motor Controller, UMC-3A K2.65000.A

Power Supply & Battery Adapter



Power Cable KC-20 K2.41966.0,
KC-29 K2.44693.0 (coiled)



Battery VCLX-2 280WH 14.4V/28V, K2.47848.0
Charger for Battery VCLX-2, K2.47849.0
Cable for charger for Battery VCLX-2, K2.47850.0
Transport Case, K2.47847.0




26V power supply NG 12/26 R K2.47351.0



Battery Adapter Back for V Mount, BAB-V K2.72010.0



Battery Adapter Back for Gold Mount, BAB-G K2.72003.0



Battery Adapter Top for V Mount, BAT-V K2.72011.0



Battery Adapter Top for Gold Mount, BAT-G K2.72006.0

Body



ALEXA camera body with Lens Adapter PL Mount, K1.71000.0



Case for ALEXA K2.72030.0

ALEXA Basic Camera Set: K0.71000.0 includes:
ALEXA camera body with Lens Adapter PL Mount s/o LDS, tool set and manual (K1.71000.0)
ALEXA DTE Blanking Plate, ABP-1 (K4.72170.0)
Electronic Viewfinder, EVF-1 (K2.72008.0)
Viewfinder Mounting Bracket, VMB-1 (K2.72009.0)
Center Camera Handle, CCH-1 (K2.72007.0)
Wedge Adapter, WA-1 (K2.72002.0)
SD card, 2 GB (K2.72018.0)
Also Available*: ALEXA DTE SxS Pro Set
Also Available*: ALEXA DTE ZOOM Set

Recording & Storage



ALEXA DTE-SxS Upgrade K2.72024.0



SxS PRO card, 32 GB K2.72019.0



SD card, 2GB K2.72018.0

Support, Handles & Extras




Wedge Adapter, WA-1 (for Quick Release HD-Baseplate) K2.72002.0



Quick Release HD Baseplate, K2.47796.0




Bridge Plate Adapter, BPA-1 (for BP-3, 5, 8 or 9) K2.72001.0




Bridge Plate BP-8 K2.47090.0



Leveling Block, LB-1 K2.72017.0



Bridge Plate, BP-12 (excl. base plate & rods) K2.72004.0



Bridge Plate, BP-12 Set (incl. base plate & rods) K0.71031.0



Shoulder Pad SP-3 K2.72005.0



Low Mode Support Set LMS-3 K2.72023.0



ALEXA Rain Protector ARP-1, K2.72026.0



Centre Camera Handle CCH-1, K2.72007.0



Side Camera Handle, SCH-1 K2.72016.0



Adjustable Center Grip tall, ACG-2, K2.72022.0



Camera Handgrip Right K4.44413.0



Camera Handgrip Right K2.45886.0



Handle Extension Block HEB-1, K4.65107.0



Handle Extension Block HEB-2, K2.72015.0



Extension for Handgrip K2.47136.0